



PRECISION PLUMBING PRODUCTS



INSTALLATION:

LAV TAIL PIECE TRAP PRIMER Part #: LTP-1500

- Insert slip joint nut onto tailpiece
 - Insert 1-1/2" or 1-1/4" slip joint washer onto tailpiece.
 - Insert p-trap body onto lav tailpiece.
 - Slide nut and washer onto p-trap body and lightly tighten.
 - Insert deep wall escutcheon onto wall tube and push wall tube through waste hole in wall.
 - Install slip joint elbow into p-trap body and lightly tighten.
 - Align wall tube and slip joint elbow to allow the wall tube to be threaded into the slip joint elbow.
 - Apply Teflon tape to compression elbow threads and 1/2" compression coupling.
 - Thread compression elbow into p-trap body until tight and hose connection threads are towards wall
 - Insert small escutcheon onto primer tube protruding from wall.
 - Install 1/2" compression coupling onto primer tube.
 - Thread flexible braided hose onto compression elbow and 1/2" compression coupling.
 - Tighten all nuts. Check for leaks.
- Specify with confidence - Install with pride[®]



<p>PRECISION PLUMBING PRODUCTS Division of JL industries, inc. www.pppinc.net Airport Business Center • 6807 N.E. 79th Court, Suite E Portland, Oregon 97218 • (503) 256-4010 FAX: (503) 253-8165</p>	<p>DISTRIBUTED BY:</p> <p style="text-align: right;">II-LTP-01 Rev. 01/07</p>
---	--